Please read this booklet carefully as it contains important information regarding the proper use of this chair and details the location of the child safety lock.

- **Adult Supervision** – Do not leave children unattended while using the chair. Do not allow any climbing, standing, leaning, or jumping on the chair. Failure to do so may cause damage to the product, potentially leading to accidents or injury.
- **Setup & Pack Down** – This chair employs a quad-fold design for convenient transportation and a compact pack size with plastic grommets at the frames cross sections that reduce the risk of any pinching. However, to ensure safety, we recommend keeping your child at a safe distance from the chair during these processes to prevent the risk of any accidents.
- **Weight Rating** – Do not exceed this chair's weight rating of 80kg. Failure to comply with the specified load capacity may lead to product failure, potentially leading to accidents or injury.
- **Children Only** – The size of this chair is designed specifically for children; despite the chairs weight rating of 80kg it is not suitable for adults.
- **Child Safety Lock** – When setting up the chair, ensure the lock has 'clicked' into place. This prevents the chair from collapsing during use. Failure to apply the lock during setup may result in accidents or injury. Failure to release the lock when packing down may lead to excessive stress being applied to major parts, potentially leading to accidents or injury.

Safety Lock Location

